

A consumer unit or fusebox is used to control and distribute electricity around the home. It usually contains a main switch, fuses or circuit breakers and one or more residual current devices (see RCD).